



PepperBall®


VKS™ 15 ROUND WINDER MAGAZINE

QUICK START GUIDE


WARNING: THIS PRODUCT IS NOT A TOY AND IS INTENDED FOR SELF-DEFENSE ONLY. There may be state or local restrictions on the purchase, possession, and use of the VKS™ 15 ROUND WINDER MAGAZINE. Verify the legal requirements in your state and city to ensure proper possession and use. The user assumes liability for unsafe or improper use, or any actions that violate applicable laws or regulations. The VKS™ 15 ROUND WINDER MAGAZINE may be prohibited in certain locations, including government buildings, airports, courthouses, schools, or other public spaces, and its use may subject the user to criminal liability.

 **WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.**

MAGAZINE OVERVIEW





OPERATIONAL INSTRUCTIONS




1. With the magazine in your left hand and the winder knob facing towards you, turn the winder knob to the right (clockwise) until it stops. Roughly 6 full turns.
2. Load 15 PepperBall® round or VXR™ projectiles. VXR™ projectiles should be loaded in the same manner as all PepperBall® launchers, with the nose pointed towards the front. **Do not partial load.**

3. Confirm projectiles are securely in place by moving projectile retainer back. Projectiles should **NOT** be ejected from the magazine.
4. Firmly insert into VKS™ magwell. You should hear an audible “click” as the VKS™ interacts with the projectile release and projectile retainer. The projectile release engages with the VKS™ regulator, releasing tension on projectile stack.



TROUBLESHOOTING

1. Do not partially load this magazine. You **must** load it with 15 PepperBall® round or VXR™ projectiles.
2. Do not wind up the magazine and press ball release without projectiles. This will damage the magazine.
3. The projectile pathway TWISTS the projectiles, this is normal. Do not try to straighten projectiles once they're loaded. The follower also twists inside the pathway. This is normal—see illustration below for an example of a VXR™ mid twist.



Continued on other side

TROUBLESHOOTING CONT.

4. If you break a projectile in your VKS™, remove the magazine before trying to clear the broken projectile. Clear powder and projectile fragments before returning to use.
5. If the follower becomes stuck inside the magazine, try turning the winder knob to clear the jam. If that does not work, use a SWAB squeegee (included in armorer kit) to push the follower while turning the knob.



PepperBall® A Division of United Tactical Systems, LLC
28101 Ballard Drive, Suite F
Lake Forest, IL 60045

Pepperball.com | (877) 877-3773

020325